

A. Artifact Appendix

A.1 Abstract

This artifact shows two major software sections of **MIMSID**, a high-resolution mmWave imaging system using metasurface and diffusion. We provide our end-to-end optimization model and signal-to-diffusion model, as well as some corresponding data for training and evaluating our models.

A.2 Artifact check-list (meta-information)

- **Algorithm:** We present our end-to-end optimization model and signal-to-image model.
- **Program:** A set of data collected by our system is provided in our artifact, including channel matrix **A** and evaluation data.
- **Model:** We utilize diffusion models DDPM and DDIM in our system, which are included and implemented in our code.
- **Data set:** We use FashionMNIST dataset for model training, the download process is executed automatically in our code. We also provide some real-world measurement data for model training and evaluating.
- **Run-time environment:** Our codes are implemented and tested on Windows 11 OS.
- **Hardware:** Our codes are tested on an NVIDIA GeForce RTX 3060.
- **Execution:** The training process may run for 1 hour. The evaluation process using the pre-trained model takes less than a second per sample.
- **Metrics:** The RMSE of the imaging system and the inference time are evaluated.
- **Output:** For the end-to-end optimization, a codebook of phase-shifting for the mmwave radar is the output. For the signal-to-image diffusion model, the outputs are image pairs of reconstructed and ground-truth images.
- **Experiments:** Please set up the experiment environment based on the requirements in Installation or run script setup.py for a Windows OS meeting our requirements.
- **How much disk space required (approximately)?:** This artifact is less than 3GB in total.
- **How much time is needed to prepare workflow (approximately)?:** The time for preparing the workflow should be less than 1 hour.
- **How much time is needed to complete experiments (approximately)?:** The full experiments should be completed in less than 3 hours.
- **Publicly available?:** No

A.3 Description

A.3.1 How to access

The whole code and evaluation dataset can be downloaded from GitHub:

<https://github.com/dozenw/MIMSID.git>

A.3.2 Hardware dependencies

- CPU: No explicit requirements, but should be able to run the required software.
- RAM: At least 8 GB
- GPU: A CUDA-enabled GPU (our codes are tested on an RTX 3060 with CUDA 12.4).

A.3.3 Software dependencies

Windows or Linux based operating system with the latest conda and Nvidia driver (version number 470 or later). We use Windows 11 and conda 23.1.0.

Requirements:

The detailed package requirements are described on our github repository.

We recommend to use cuda 12.4, torch 2.6.0, and torchaudio 2.6.0, and torchvision 0.21.0.

The **fashion-mnist.train.csv** and **fashion-mnist.test.csv** are provided in

https://pan.baidu.com/share/init?surl=tk_yZyuzoA26Vy_VeNzsQg&pwd=v16u
or
<https://drive.google.com/drive/folders/1p8zrBXasdzsQb-eiKvT9usp?sharing>

A.4 Installation

Step 1. Extract the artifact repositories via git clone and cd into it.

```
git clone https://github.com/dozenw/MIMSID.git
cd artifact/MIMSID
```

Step 2. Create Conda environment and activate it.

```
conda create -n MIMSID python=3.9.13
conda activate MIMSID
```

Step 3. Install CUDA 12.4.

```
conda install -c "nvidia/label/cuda-12.4"
cuda-toolkit
```

Step 4. Install requirements.

```
pip install -r requirements.txt
```

A.5 Experiment workflow

A.5.1 End-to-end optimization

To run the end-to-end optimization, simply run

```
python e2e_optimization.py
```

The optimized codebook will be printed out and the corresponding channel model will be saved in **mts_model** folder.

A.5.2 Signal-to-image diffusion

To test the Signal-to-image diffusion model, simply run

```
cd sig2imgDM
python main.py
```

The default program is running in evaluation mode. To activate the training process, run

```
python main.py --if_Train=True
```

When activating training, the model is stored in the **sig2imgDM** folder with the name **conditional_ddpm_width192_fmniist_Aytrain.py**.

To disable evaluation, run

```
python main.py --if_Eval=False
```

A.6 Evaluation and expected results

The example output is included in our github page. **MIMSID/sig2imgDM/ output** shows image pairs of reconstructed (named with suffix "_est") and ground truth (named with suffix "_gt") images. The evaluated RMSE should be under 0.06 with mean inference time less than 0.2 seconds.

A.7 Experiment customization

End-to-end optimization To customize, you can alter the iteration steps of the initialization and the learning rates of the models

in the "if __name__ == '__main__':" section. You can also modify the training steps in function **optimize.step**. In addition, you can modify the parameters of class **mmWaveSimulator**, where the target's distance, image resolution, and metasurface size can be altered.

Signal-to-image diffusion To customize, you can modify the training epochs **n.epoch** and learning rate **lr** in the training section.

A.8 Notes

A.9 Methodology

Submission, reviewing and badging methodology:

- <https://www.acm.org/publications/policies/artifact-review-and-badging-current>
- <https://cTuning.org/ae>